

CONVECTION OVEN LIGHTING INSTRUCTIONS

1. PLUG IN ELECTRIC CORD
2. CONNECT PROPANE LINE TO PROPANE TANK (REVERSE THREADS)
3. TURN MAIN VALVE OFF (FRONT OF OVEN)
4. HOLD FLAME TO MAIN BURNER (BEHIND LOWER HINGED FRONT DOOR)
5. PUSH IN ON RED SAFETY BUTTON (ABOVE MAIN VALVE) IN.
6. AFTER PILOT LITES, HOLD IN 30 SECONDS- THEN LET GO- PILOT WILL STAY LIT.
7. FOR MAIN BURNER- SET THERMOSTAT TO 500° - TURN MAIN VALVE ON.
8. RESET DIAL TO BAKING TEMPERATURE



513-521-6500

9832 Hamilton Ave. Cincinnati, OH 45231